

To joint using tapes, ensure the first panel of Barrier is laid, and the surface is clean, dry, and free from dust. Begin by peeling one side of the protective coating from the tape, applying the tape along the outside edge of the 200mm guide line; such that the tape is between 100mm and 150mm from the Barrier roll edge. Unroll the second layer of Barrier ensuring a 150mm overlap, slowly removing the upper layer of

protective film from the Tape, and pressing firmly on the taped joint with a silicone roller to remove trapped air. (Note - taped joints have the highest failure rate when tested to ASTM D4437-08:2013 'therefore it

is imperative that pressure sealing with silicone roller is implemented)

Tel: 01772 754177